

Manual

SolidSky

Assembly & Installation Manual V.08

* * ATTENTION * *

AVZ Group cannot be held liable for any errors that may occur in this manual, nor for any adverse consequences arising from the use of this manual.

Contents

General information

| Basic dimensions |
|-------------------------------|
| Determining the cutting sizes |
| Side guide supports |
| |
| SolidSky assembly |
| Preparation of profiles12 |
| Assembly of fabric roller13 |
| Assembly of front profile15 |
| Assembly of casing17 |
| Assembly of side guides |
| |
| SolidSky installation |
| Installation of casing |
| SolidSky installation25 |




General information

General information



Basic dimensions



SolidSky

Width: Min. 800 mm Max. 4000 mm Projection: Min. 1000 mm Max. 3000 mm


Up to 2000 mm always uses a motor with a torque of 20 Nm. Number of supports: 2 pieces per side guide.

From 2000 mm always uses a motor with a torque of 25 Nm. Number of supports: 3 pieces per side guide.

Determining the cutting sizes

| Picture | Description | Formula | Number | Cutting size (mm) |
|---------|---------------|--|--------|-------------------|
| | Top cover | Width - 6 mm | | |
| | Bottom cover | Width - 6 mm | | |
| | Front profile | Width - 145 mm | | |
| 5 | Steel tube 78 | Somfy width - 113.5 mm ASA width - 112.5 mm | | |
| F | Side guide | Projection - 140 mm | | |
| # | Plastic guide | Projection - 150 mm | | |
| | Fabric | Width - 70 mm Projection + 100 mm | | |

Soltis Lounge Soltis 92 Soltis 86 Seamless acrylic uni fabric Sergé screen fabric





Side guide supports


Side guide support 50 high 60 9

Side guide support for coupled system 50 high

SolidSky assembly

SolidSky assembly

Preparation of profiles




Assembly of fabric roller

2.0 Attaching the fabric to the fabric roller


Slide the fabric cords into the fabric and slide the fabric into the fabric slot. If necessary, use silicone spray to allow the fabric to slide more easily into the fabric slot.

ATTENTION! Make sure that the zipper is on the underside of the fabric and that the fabric is inserted correctly into the recessed fabric slot.




2.1 Fitting of bearing roller bung into fabric roller

Fit this as shown in the picture.




2.2 Fitting of motor in fabric roller

Place the motor in the fabric roller as shown in the picture.




2.3 Rolling up the fabric

Roll up the fabric along the bottom with the zipper at the bottom as shown in the picture. Note: the roller has a recessed fabric slot.






Assembly of fabric roller



2.5 Fastening of plastic mounting plate


Fasten the plastic mounting plate to the motor using two Somfy screws.



Assembly of front profile


3.0 Fitting of plastic seal

Cut the plastic seal to the same length as the front profile and slide it into the front profile as shown in the picture.




3.1 Attaching of front profile to fabric

Slide the fabric with the fabric cord into the front profile as shown in the picture.




3.2 Installation of guide blocks

Install the guide blocks onto the front profile using 4.2 x 45 mm self-tapping screws (countersunk head/cross-head).



3.3 Mounting of wheels

Mount the wheels to both sides of the front profile using adapter screws as shown in the picture.






Assembly of front profile


3.4 Installation of end caps

Install the end caps onto the guide blocks using two 3.5 x 32 mm self-tapping screws (countersunk head/ cross-head) on both sides of the front profile.




3.5 Installation of end caps

Install the other parts of the end caps onto the guide blocks using two 3.5×16 mm self-tapping screws (countersunk head/cross-head) on both sides of the front profile. Make sure that approximately 6 mm of fabric protrudes from the end caps on both sides.



3.6 Cut off residual zipper


Cut the residual pieces of zipper as close to the end caps as possible.




Assembly of casing




Drill the 6 mm holes on the left and right-hand side. Then only drill the 9 mm hole in the top cover on the side where the motor cable runs through the top cover.






4.1 Installation of cover supports

Install the cover supports on both sides of the top cover using 3.5 x 16 mm self-tapping screws (countersunk head/cross-head).



4.2 Fastening of casing supports

Fasten the casing supports using M5 x 12 mm metal screws (countersunk head/crosshead), M5 low square nuts and M5 retaining washers.






Assembly of casing


4.3 Fitting of fabric roller in top cover

Fit the fabric roller into the top cover as shown in the picture. Lead the motor cable through the 9 mm hole in the top cover.




4.4 Mounting of bottom cover

Hook the bottom cover into the top cover as shown in the picture.



4.5 Fastening of bottom cover

Fasten the bottom cover on both sides using two 4.2 x 13 mm self-tapping screws (cylinder head/ cross-head).




Assembly of side guides

5.0 Drilling of side guides

Drill 7 mm holes into the side guides to fasten the casing supports. Position the holes on the drill line and 27 mm from the ends of the side guides.


ATTENTION! There are left-handed and right-handed side guides.

ATTENTION! Thoroughly clean and remove any chips from the insides of the side guides after drilling.




5.1 Installation of mounting plates

Install two mounting plates per side guide as shown in the picture.




5.2 Mounting of inlet guides

Mount the inlet guides onto the plastic guides using 2.9 x 19 mm self-tapping screws (countersunk head/cross-head).



5.3 Attaching of neoprene strips

Attach neoprene strips to the plastic guides every 50 cm as shown in the picture. Keep the upper strips 10 cm away from the inlet guides.






Assembly of side guides

5.4 Fitting of plastic guides

Slide the plastic guides into the side guides as shown in the picture. Make sure that the inlet funnels of the plastic guides are on the same side as the holes drilled in **step 5.0**.



Install the gas springs on the other side of the side guides as shown in the picture and fasten them with 3.5 x 16 mm self-drilling screws (cylinder head/cross-head). During installation, make sure that the steel cable of the gas spring does not touch the edge of the side guide.


SolidSky installation

SolidSky installation

Installation of casing


1.0 Preparing assembly

Before mounting the SolidSky assess whether the existing construction is suitable. Mount the Solidsky flat and perpendicular, check if this is the case by measuring angled.




1.1 Fitting of casing

Slide the casing into the side guides as shown in the picture. Make sure that the zipper of the fabric runs properly into the zipper guides.





1.2 Fastening of casing

Fasten the casing onto the side guides using M6 x 20 mm hexagonal bolts and M6 retaining washers.



SolidSky installation







SolidSky installation

2.2 Tensioning of fabric

Run the front profile downwards (pull the front profile to keep the fabric taut) and fasten the gas spring tensioners to the front profile using two M5 x 35 mm Allen screws (cylinder head).


Refer to the enclosed motor manufacturer's manual for adjustment of the motor endpoints.






2.3 Disassembly of locking plates

Let the front profile run a little upwards to allow the locking plates of the tensioning system to be removed. Keep the locking plates with all their parts.




2.4 Mounting of covers

Mount the covers as shown in the picture. Use the M4 x 12 mm Allen screws (countersunk head) that were in the locking plates for this.



Appendices

Appendices



SolidSky Assembly & Installation Manual V.08

AVZ-GROUP

Kanaaldijk 11 • 5683 CR Best • The Netherlands **T** +31 499 328 600 **E** verkoop@avz.nl